





# MiBell

Systemvoraussetzung ab iOS 14.5

## Bedienungsanleitung | Instruction Manual




①  
Öffne die MiBell. Und nimm den MiTag heraus.




Tipps und Tricks  
EVA Ø 3 mm wird nur für die Installation von AirTags verwendet, um zu verhindern, dass es wackelt.



②  
Nur Bei Verwendung von AirTags: Legen den AirTag in die MiBell mit dem EVA Ø 3 mm darunter.



③  
Für dünneren Lenker werden die Zubehörteile benötigt, um MiBell wie abgebildet zu installieren.



④  
Montieren Sie die MiBell am Lenker des Fahrrads.

⑤  
Danke, dass Sie sich für ein MiLi Produkt entschieden haben! Bitte lesen Sie die Anweisungen und Warnhinweise sorgfältig durch, bevor Sie das Produkt benutzen.

## Wichtigste Funktionen

Finden Sie Ihren Gegenstand. Das Apple® Wo ist®-Netzwerk bietet eine einfache und sichere Möglichkeit, persönliche Gegenstände auf einer Karte zu lokalisieren, indem Sie die Wo ist®-App auf Ihrem iPhone, iPad® oder Mac® verwenden. Koppeln Sie Ihr kompatibles Produkt einfach mit der Apple Wo ist®-App, um es direkt neben Ihren Apple-Geräten anzuzeigen. Das Wo ist®-Netzwerk ist verschlüsselt und anonym, so dass niemand, nicht einmal Apple oder der Hersteller Ihres persönlichen Gegenstands, seinen Standort einsehen kann.

## Kurzanleitung

### 1.1 MiTag Ein- / Ausschalten

Drücken Sie die MiTag Ein-/Ausschalttaste einmal, um das Gerät einzuschalten. Es sollte eine kurze Melodie abgespielt werden, die signalisiert, dass er eingeschaltet ist. Um den MiTag auszuschalten, halten Sie die Taste 5 Sekunden lang gedrückt.

Sie hören einen 2-maligen Piepton, der signalisiert, dass der MiTag ausgeschaltet ist.

### 1.2 Nach Updates suchen.

Um den MiTag mit der Wo ist®-App zu nutzen, wird die neueste Version von iOS, iPadOS® oder

macOS® empfohlen. Die App „Objekte suchen“ auf der Apple Watch erfordert die neueste Version von watchOS®.

### 2.1 Vorbereitungen.

Schalten Sie die Bluetooth und die WLAN- /

Mobilfunkverbindung Ihres Telefons ein.

Vergewissern Sie sich, dass die Ortungsdienste in den Telefoneinstellungen aktiviert sind.

Im Modus „Verloren“ kann Ihr MiTag nicht mit einem neuen Gerät gekoppelt werden.

### 2.1 MiTag aus Wo ist entfernen.

Öffnen Sie die Wo ist®-App auf Ihrem iPhone.

**Technische Hilfe nur über E-Mail Support  
Technical assistance via email support only:**

support@ultron.de

**Kontakt | Contact**





Robert-Koch-Str. 7-17  
52499 Baesweiler  
Germany

Mail: info@ultron.de  
Internet: www.ultron.de

Vorstand: Achim Heyne  
Vorsitzender des Aufsichtsrates:  
Martin Heyne

Sitz der Aktiengesellschaft: Aachen  
Registergericht: Amtsgericht Aachen  
Registernummer: HRB 8697  
Umsatzsteuer-ID: DE217697553

MADE IN  
CHINA



Thank you for choosing a MiLi product!  
Please read the following instructions and warnings carefully before using the product.

### Main Functions

Locate your item The Apple® Find My® network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad®, or Mac®. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location. Quick instructions

### Quick Guide

#### 1.1 Power On / Off

Press the MiTag Switch on/off Button once to turn it on. It should long beep once to indicate that it is powered on. To power off, hold the same button for 5 secs. You will hear 2-time beep to indicate that your MiTag is powered off.

#### 1.2 Check For Updates

To use the Apple Find My app to locate this item,

the latest version of iOS, iPadOS®, or macOS® is recommended. The Find Items app on Apple Watch requires the latest version of watchOS®.

### 2.1 Add Your MiTag

Start The App, Open Find My app on your supported iPhone. Turn on the bluetooth and network of your phone.

### 2.2 Connect Your MiTag

Press the switch on/off button once to power on your MiTag, then „Add Other Item“. Once your MiTag is located, tap „connect“. Enter a name and choose an emoji for your MiTag and tap „Continue“. Find My will ask for confirmation to your Apple ID, Tap „Agree“ and „Finish“, then your MiTag will be set up and ready to be used.

### 3.1 Find MiTag When It's Nearby

Open Find My app and select the „Items“ tab or open the Find Items app on your Apple Watch. Tap your item from the list. Tap „Play Sound“ to make your MiTag beep. Tap „Stop Sound“ to stop the beeps once you find it.

### 3.2 Find MiTag Location

Open Find My app and select the „Items“ tab or open the Find Items app on your Apple Watch. Tap your MiTag from the list. Your MiTag location will appear on the Map with a time stamp of when the item was located. To navigate to the MiTag's location, tap „Directions“ to open Apple Maps.

### 4.1 Notifications

Enable „Notify When Left Behind“. Open Find My app and select the „Items“ tab or open the Find Items app on your Apple Watch. Tap on your item from the list. Under „Notifications“, enable the „Notify When Left Behind“ toggle. You will receive a notification when you leave your MiTag behind and it's no longer in range of your device.

#### 6.1 Resetting MiTag

Remove The MiTag From Find My App Open Find My app and select the „Items“ tab. Tap on your item from the list. Please ensure „Lost Mode“ is disabled. Scroll to the bottom of the screen and tap „Remove Item“. A summary will open, tap „Remove“ to confirm.

#### 4.2 Enable „Notify When Found“

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### 5.1 When Your MiTag Is Lost - Enabling „Lost Mode“

Open Find My app and select the „Items“ tab or open the Find Items app on your Apple Watch. Tap on your item from the list. Tap „Play Sound“ to make your MiTag beep. Tap „Stop Sound“ to stop the beeps once you find it.

### 5.2 Find MiTag Location

Open Find My app and select the „Items“ tab or open the Find Items app on your Apple Watch. Tap your MiTag from the list. Your MiTag location will appear on the Map with a time stamp of when the item was located. To navigate to the MiTag's location, tap „Directions“ to open Apple Maps.

### 6.2 Factory Reset Your MiTag

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### 7.1 Unwanted tracking

Open Find My app and select the „Items“ tab or open the Find Items app on your Apple Watch. Tap on your item from the list. Tap „Play Sound“ to make your MiTag beep. Tap „Stop Sound“ to stop the beeps once you find it.

### 7.2 Play Sound

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### 8.1 Power On

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### 8.2 Power off

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### 8.3 Reset

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### 8.4 Play Sound

Under „Notifications“, enable the „Notify When Found“ toggle. When your MiTag is seen by another Find My network device, you will receive a notification of its location. Note: „Notify When Found“ can only be activated when your MiTag is out of range.

### Button & Sound Description

ON/OFF

Click the button (long beep)

Hold the button for 5 seconds (2-time beep)

Click the button 5 times then hold until three is a long beep (please remove MiTag from your Find My App before reset it)

Press „Play Sound“ in the App (1-time beep)

### Technical details

Powersupply: CR2032 button battery  
Requirement: iOS 14.5 or later  
Operating voltage: 2.0V-3.6V  
Transmission distance: 40-50m (open environment)